

Attaching Instructions

INTERNATIONAL[®]

Blade

(42-inch)

with

Spring Trip

(549 674 R91)

for

INTERNATIONAL[®]

Cub Cadet

86, 108, 109, 128, 129 and 149

Tractors

Serial No.


400,001

and

up

ATTACHING INSTRUCTIONS


STEP 1. PIVOT FRAME, MAIN FRAME AND LIFT ARM



Illust. 2

ATTACHING INSTRUCTIONS

STEP 2. SUBFRAME



MA-7209


Illust. 3

Place slotted ends of the subframe on the foot rest rods as shown in Illust. 3.

It may be necessary to spread the slotted ends of the subframe in order to place the subframe on the foot rest rod.

ATTACHING INSTRUCTIONS

STEP 3. SUBFRAME AND MAINFRAME




Illust. 4

Raise the blade subframe until it latches in place at the quick attach latch on the tractor frame. See Illust. 4.

Attach the blade main frame to the subframe as shown in Illust. 4.

ATTACHING INSTRUCTIONS

STEP 4. LIFT ROD, SPRINGS AND BLADE



Illust. 5

Note #1: Pitch blade rearward and connect the springs.

Note #2: Pitch blade forward and down to attach pivot frame to blade, using pivot rod and cotter pins. See Illust. 5.


Attach the lift rod to the lift arm of the blade and to the lift handle or rockshaft arm,

depending on the type of lift the tractor is equipped with. Refer to Illusts. 5, 6, and 6A.


Note: Refer to the Operator's Manual for correct operating instructions for Manual Lift, Electric Lift, or Hydraulic Lift.

ATTACHING INSTRUCTIONS

STEP 4. LIFT ROD, SPRINGS AND BLADE—Continued



Illust. 6



Illust. 6A

DETACHING INSTRUCTIONS

Drive the tractor with the blade to storage location.

Lock the tractor brakes and lower the blade to the ground.

Remove the lift rod from the lift handle or rockshaft arm and lift arm.

Press down on the quick attach latch (Illust. 4) and pull the blade from the tractor.

To reattach the blade to the tractor, reverse the above procedure.





For Your Protection

Use IH Parts

TO THE OWNER—

You have just purchased one of the finest pieces of equipment available today. You can look forward to years of good service because International Harvester machines are designed better and built better to last longer.

When you need to purchase replacement parts or have your equipment serviced, we will be here, ready to serve you.

We stock genuine IH parts—the parts that are designed for your equipment, not just made for it.

We also offer you IH Blue Ribbon Service—the service that puts your equipment back to work in minimum time at an economical cost. We are here to serve you—call on us in the future.

Sincerely,

Your IH dealer

INTERNATIONAL HARVESTER COMPANY • 401 NORTH MICHIGAN AVENUE • CHICAGO, ILLINOIS 60611, U.S.A.